

## Mounting:

1. Locate the mounting place on your vehicle\*, make sure it is mounted properly on a strong location such as the roof. If necessary use brackets to make a flat surface for the awning to mount to. Brackets can be supplied to mount the Weather shade to most roof racks, load bars etc.
2. Measure the location of the holes for the screws. Bring the mounting locations as far out as possible for best support. Rear mounting must be done through Stainless Steel Hinge- 4x M8 pre-drilled holes.
3. Open up the Awning and drill the desired holes from the inside out. Heat up the drill bit before use!
4. Put button head bolts through the holes from the inside of the awning and carefully lift the awning to where it should be fitted. Apply nuts on the other end and tightly secure the awning to the vehicle.

**! Do not try to do this alone! Ask others to help lift the awning while one person tightens the nuts and bolts.**

5. Close the zipper.

\* Measures for mounting in image below

